



The stone lid trays should be set in the following manner:

1. Set ME and NME trays FIRST. In front & back install a 6" piece of angle at pit end wall. ME & NME trays will hang over the angle bracket. DO NOT TRIM THESE TRAYS. The tray should be set so that the top edge of the tray aligns with the underneath of the coping. The lip on the tray MUST NOT be higher or lower than the bottom of the coping. Repeat this on the NME.
2. Once the ME & NME are set on the bench angle, lay out the remaining trays evenly spaced behind the pit. These trays can be trimmed to fit upon your discretion. However, it is best to trim the center tray for a uniform look.
3. To mount the brackets, set the first bracket, 4" from the track edge (or approximately 6" from tiled pool wall), with the edge of the ME tray centered on the bracket w/ the extension attached, and mount using bracket hardware. Lay the tray in place. Place the next tray on that bracket arm and scribe a line on the pit wall to mark the end of the tray. Mount the bracket using the scribed line as a center mark. The line should divide the bracket in half. Mount the bracket, set the appropriate tray on top of it, and repeat the scribing process. Repeat the bracket installation until all brackets are mounted.
4. Once brackets are mounted, slide off extensions. Once the cover is installed, the arms and extensions can be replaced and you are ready to set the stone lid.

NOTE: Make sure the front edge of the extensions are 1/2" shorter than the stone or trays. Also, be sure the underneath and front of the extensions are filed smooth to prevent cover damage.